



U R B A N

514.932.8227

INFO@URBANBONFIRE.COM

Kitchen Installation Protocol

1. Measure out installation area. Mark kitchen location
2. Attach legs to cabinets. Tap with a mallet to secure.
3. Place in proper sequence. (See “Cabinet Technical” sheet)
4. Install side panels, making sure to include sliding toe kick. (#8 screws)
5. Install back panels. , making sure to include sliding toe kick. (#8 screws)
6. Assemble cabinets together (#8 screws in front and 10-32 bolts at back)
7. Level
8. Unpack countertop and review installation numbers. (See “Countertop Technical” sheet)
9. Place countertop on light bead of silicone. Shim where necessary.

Allow silicone to dry for approximately 1hr. In the meantime:

10. Attach rubber bumpers inside doors
11. Attach toe kicks. 2 parts
12. Install and test accessories (trash, shelves, etc...)
13. Dust clean and polish doors and handles. (As per “Maintenance Guide” sheet)
14. Unpack equipment. Attach built-in brackets when necessary.

Once silicone has set:

15. Place equipment as per manufacturer's specifications.
16. Pick up all packing and sweep area.
17. Photograph installation and contact project manager.